




E I C H H O L T Z

104014 TELESCOPE KENTWELL


ASSEMBLY INSTRUCTION

1 While resting one leg on the ground gently expand the other two legs.

Slightly loosen the wing nuts & press the centre tubes down to extend the legs to the desired height one by one. Tighten the wing nuts securely.



2 Place the binoculars on the stand. Tighten the knob so the binoculars are secured on the stand.



3 Use the lever to fix the binoculars in the desired direction.

